



Installation Requirements – Please Read Before Installing Your Airack Glass Dryer

AIRACK Installation Details

Siting

Unpack the Airack in the area in which you intend to use it. The Airack must be sited on a sound level surface with adequate clearance for servicing, ideally within close proximity to your Glasswasher and no further than one metre from an electrical socket. It is recommended that the Airack is placed on top of your Glasswasher or on top of the bar area.

The Airack can be mounted onto a purpose made basket stand providing optimum working height. It is recommended that if your Airack has been supplied mounted on a basket unit it is placed within close proximity to your Glasswasher and no further than one metre from an electrical socket.

Filter (Not Supplied With The Airack Lite)

The Airack is supplied with one filter. Invert the Airack to give access to the air filter. Sometimes the filter frame can become loose in transit. Check that the filter is aligned to the base and the frame is secured with the four clips. Note, the clips are tight and care should be taken if they need to be removed.

Electrical

The Airack is supplied for connection to a 240v 3 pin socket with a 1 metre mains cable. An RCD is recommended. Check that the supply voltage is within the range stamped on the plate fitted to the underside of the unit.

The socket in which the Airack is to be plugged must be no further than 1 metre away from the Airack and must be used for the Airack only.

Drain (Not Supplied With The Airack Lite)

A rubber outlet pipe (19mm O.D.) is supplied with the Airack. This needs to be fitted to the unit to remove any excess water build-up resulting from the draining/drying process. When connected the pipe needs to be placed into a drain up stand or receptacle within 1 metre of the unit.

If You Require Help



Owners Manual

Refer to USB stick for more information and advice



Service and Sales

Tel: 01933 666244



Website and Email

www.clenaware.co.uk
info@clenaware.co.uk




Installation Diagram - Please see the reverse for a full Installation Diagram




Installation Requirements – Please Study Before Installing Your Airack Glass Dryer

AIRACK
Installation Diagram


Siting



Air Filter



Basket Placement



Top Cover Placement

